


ELWA HOTRUN-VE RANGE

SETTING THE TEMPERATURE LIMITER

For the programming of the temperature limit already in the software:
Water heater needs to be connected to the electric power supply.

1. Switch the water heater off with the off button on the water-heater



2. Hold the up- and down temperature button pressed for 10 seconds
3. Set the temperature limit that is required (max is 60°C)
4. Press the on/off button to store the temperature limiter setting
5. Switch the water heater back on with the on/off button
6. Check the temperature limit programmed by raising the temperature with the up-button and make sure it doesn't exceed the required temperature limit programmed
7. If the temperature limit is not stored, repeat the above programming and check again