

Code    Most likely cause

F1      Temperature sensor not connected (reconnect)

F0      Temperature sensor short circuit (replace temperature sensor)

HH      Too high inlet or outlet temperature >75°C

LL      Inlet water temperature too low <5°C

LF      Inlet water flow too low should be < 2.5 ltr/min for the most models

OT      Over Temperature/Over Pressure safety switch tripped (reset button)